




Connecting Pipes > Connecting Adapters

Internal Claypipe System


Note:
All joints must be sealed with fire cement



For use where there is limited room and you can only insert up into the clay pot.


External Claypipe System

Note:
All joints must be sealed with fire cement



For use where there is sufficient room to "cup" the end of the clay liner

Sump Adapter



The sump adapter is inserted into the bottom of the flue pipe and then fixed to the chimney. It is sealed with Fire Cement or Fire Rope where the Sump Adapter sits in the flue pipe.

